

Requirements

This product is designed for vertical window blinds made of vinyl/plastic. Each individual vane MUST measure 3 ½ inches in width. The maximum width of the printed images will be 60 inches (19 individual vanes). The maximum height for all printed images will be 48 inches.

Installation Methods

Upon opening product, carefully remove plastic packaging. DO NOT MIX-UP the order in which the image sleeves are packaged. The top sleeve is marked number #1. This is the first sleeve to be installed. All sleeves are packaged in their respective order. Failure to install in the received order may result in confusion of the proper order of the blinds in relation to the orientation of the image.

STEP 1). Centering the Image

Count the total number of the individual vanes on the window blinds, then count the number of sleeves (without mixing them up). Subtract the existing window blind vane number by the number of sleeves from the kit. For Example, if you have 26 total window vanes and 16 image sleeves, there will be 10 blank vanes and 5 of these on each side will center the image.

STEP 2). Measuring

With a scaled ruler, draw a pencil line at least 6 to 10 inches from the top, evenly at the top of each existing window blind vane to provide a reference mark, to evenly install each printed image on the sleeve evenly. After removing the BLUE protective masking of each image sleeve, install the folded edge of the first image sleeve (marked #1), 6 to 8 inches from the top of the first (pre-determined) existing window vane. Do this on the first pre-measured existing vane, from the desired right /left hand end. If the original window blind overlaps to the LEFT HAND SIDE, start (with #1) on the LEFT HAND END. Adversely, if the window blind overlaps to the RIGHT HAND SIDE, start (with #1) on the RIGHT HAND END. Remove blue masking (covering) ONE AT A TIME, and install each sleeve image ONE AT A TIME, to keep image sleeves in order.

STEP 3). Installation

Install all sleeves repeatedly, without their captive edge, until all sleeves are aligned evenly at the top and aligned evenly without any gaps along the folded edges. You may be able to adjust any single image sleeve that is not aligned evenly (from top to bottom) with the others image sleeves before installing the captive strip along the covered edge at this time.

STEP 4). Finishing

Apply the cap strip on the opposite side of the folded edge of the image sleeve (the side hidden under the overlapped side).

Final adjustments can be made anytime after installation including centering, by removing each existing window vane and replacing it with the pre-installed image sleeve next to it, by inserting a plastic card into the "fish" hook hanger, and alternating, by removing each vanes position, to achieve a centered or off-centered viewed image.